

### LCN9810 NFC scanner Datasheet

#### NFC scanner

Incase you have problems reading a driver, we recommend using an NFC scanner.

- When your smartphone has no or weak NFC antenna
- When you cannot reach the driver with your smartphone
- Some drivers cannot be read by some smartphones running on Android 9 (or higher). This NFC scanner will solve this.

This device communicates via BLE with your smartphone.

The NFC scanner has a secure BLE connection with the smartphone

The NFC scanner is available in the sample web shop:


Home page | Philips OEM Sample Shop EMEA

BLE = Bluetooth Low Energy

NFC = Near Field Communication

# The NFC scanner enables you to read/write Philips drivers









#### How to use the NFC scanner?

- Make sure the battery of the NFC scanner is charged sufficiently, use the micro USB connector near the key-ring to charge. A low battery will have less good communication capabilities
- Switch on the NFC scanner by the pushbutton (see previous slide)
- The scanner will switch off automatically after approximately 5 minutes
- Position the antenna of the scanner parallel to the antenna of the driver for optimal connection (see explanation next slide)
- In case the communication is not as good as can be expected, please experiment by changing the position of the NFC scanner relative to the driver
- When reading or writing data to or from the driver you do not need to push the pushbutton



#### Best position of the NFC scanner relative to the PHILIPS driver







### Button, LED's and Beeper

Action	Light Displayed	Light Sequence	Beep Sequence	Status - Function		2 sec. hold	0 🔷 0	•		Shutdown	
	0 🔷 0			Off			0 🔷 0	<b>-0-0</b>		Battery Low	Status
1 sec. hold	0 🔷 0	0 0	•	Start Devices		USB connected	000	• • • • • • • • • • • • • • • • • • • •		Battery Recharge	Battery
	• 🔷 0			Power On		plugging USB	000	0 0	•	Start Devices	
	• 🔷 0	000		Scanning	ons		0 🔷 0	• • • • • • • Max 10 s		Battery Low no operations allowed	
	•�•	0	• • •	Successful reading	) Function		0 🔷 0	• • • • • • • • • • • • • • • • • • • •		Bluetooth disconnected	
	• 🔷 0		• •	Reading error	Scar	6 sec. hold	0 🔷 0			Hardware reset	



## Specifications

Details	Specifications					
Man/Machine Interface	1 function key for RFID read activation, Multitone Beeper, 2 LED for device operation signaling					
Internal Devices	Frequency: 13.56 MHz ; Power: 200 mW Standard: ISO 15693, ISO 14443A/B, NFC Type-2 Tag, NFC Type-4 Tag, NFC Type-5 Tag, ST25TB ; Read range: up to 6 cm ; Embedded antenna					
Interfaces	Micro USB type B, Bluetooth® Low Energy					
OS Compatibility	iOS, Android, RIM, Windows Mobile/Phone, Windows, macOS, Linux					
Processor	Texas Instruments MSP430 (16bit RISC a 16MHz)					
Power Supply	USB powered: 230mA peak @ 5Vdc (RF active full power), 30mA @ 5Vdc (idle mode) Battery powered: Li-Poly Battery 3.7Vdc 300mAh, rechargeable via micro-USB Battery life 15000 readings, 14 h in idle mode					
Working Temperature	-20°C / 60°C					
Dimension	Height 7.7 cm - Width 4.3 cm - Depth 1.7 cm					
Weight	21 g					
Protection Degree	IP 54					



#### ANNEX MultiOne Mobile – example of Specification format

```
Summary_Xi SR 40W 0.2-0.7A SNEMP 230V C133 sXt 22-10-2020 16-04-50.txt - Notepad
File Edit Format View Help
 "aloValue": "78%",
 "aocValue": "200mA",
 "dateAndTime": "22 oktober 2020 16:04:24",
 "deviceName": "Xi SR 40W 0.2-0.7A SNEMP 230V C133 sXt",
 "dynadimValue": "Not Enabled",
 "firmwareVersion": "1.0",
 "globalProductCode": "929001573506",
 "gps": "51.3584784, 5.3301111",
 "historyFaultCode": "[0, 0, 0, 0, 0, 0, 0, 0, 0, 0]",
 "systemOnTime": "0 hr(s) 0 min 0 s",
 "systemStartsCount": "0",
 "uniqueProductId": "E0024D84D8C27041"
```



# Signify