





PHILIPS

Maxos fusion

LL500E Gen2



LL500E IA4 SR2DALI Gen2
(with SC200B-02 SR
SENSOR)





kg
0,69

	FRONT SIDE							BACK SIDE						Trunk Compatibility		
	PE	N	L1	L2	L3	4	5	6	7	8	9	10	11	LL...T 7...	LL...T 9...	LL...T 13...
LL500E IA4	PE	N				DA+	DA-							✓	✓	✓


IMPORTANT INFORMATION - READ BEFORE INSTALLATION

- for use with panels with DIA drivers only. DON'T USE with PSD, SRD and SIA drivers (high risk of DAMAGE)
- use trunk to trunk connector supplied with the sensor unit to separate DALI lines between two trunks to separate a group of 1 sensor + max. 20 drivers from another group along the light line
- use max. 20 panels per one DALI line segment
- do not connect more than one sensor unit to one DALI line segment
- do not connect more than one emergency light unit to one DALI line segment
- do not connect any external power sources to DALI
- max 25 m distance (line-of-sight) between sensor units




Installation of the delivered T2T connector to separate DALI lines

1. Take the T2T connector delivered with LL500E IA4 SR2DALI Gen2 out of the box




LL500E IA4 SR2DALI Gen2 Box

2. Remove preinstalled standard T2T connector





3. Install T2T connector delivered with LL500E IA4 SR2DALI Gen2



442710484364

2025-01-30
© Signify Holding
All rights reserved

Installation of the LL500E IA4 SR2DALI Gen2



- Minor movement (person moving ≤ 0.9 m/s).
- Major movement (person moving ≥ 0.9 m/s)..



Height	Minor Movement		Major Movement	
	X1	Y1	X2	Y2
2.4 m	2.7 m	2.7 m	4.5 m	4.5 m
2.8 m	3.6 m	3.6 m	5.4 m	5.4 m
4.0 m	3.6 m	3.6 m	5.4 m	5.4 m
6.0 m	n.a.	n.a.	5.4 m	5.4 m

Note: Longer dimension of detection area (Y1, Y2) is parallel to longer dimension of SC200B-02 SR SENSOR

