

INSTALLATION INSTRUCTIONS



PHILIPS

SLENDERFORM LUMINAIRE MOUNTED ON PTF2 (3-1/2" O.D),  
PTF3 (4-1/2" O.D) OR PTF4 (5" O.D) POLE TOP FITTER.

443561200940  
SHEET 1 OF 2

© 2013 Koninklijke Philips Electronics N.V. All rights reserved.

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PERFORMING ANY WORK.**  
**BE SURE ALL POWER IS OFF PRIOR TO INSTALLING LUMINAIRES.**



FITTER TYPE	"X" DIA. (Ø)	USED ON TENON SIZE
PTF2	3-1/2"	2-3/8" TO 2-7/8" O.D. X 4" HIGH
PTF3	4-1/2"	3" TO 3-1/2" O.D. X 6" HIGH
PTF4	5"	3-1/2" TO 4" O.D. X 6" HIGH

# INSTALLATION INSTRUCTIONS

SLENDERFORM LUMINAIRE MOUNTED ON PTF2 (3-1/2" O.D),  
PTF3 (4-1/2" O.D) OR PTF4 (5" O.D) POLE TOP FITTER.

**PHILIPS**


443561200940

SHEET 2 OF 2

© 2013 Koninklijke Philips Electronics N.V. All rights reserved.


**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PERFORMING ANY WORK.  
BE SURE ALL POWER IS OFF PRIOR TO INSTALLING LUMINAIRES.**

1. LOCATED ON THE BOTTOM OF THE ARM ASSEMBLY, LOOSEN (2) #8-32 SCREWS USING SCREWDRIVER. OPEN ARM ASSEMBLY.
2. APPLY A BEAD OF SUITABLE WEATHERPROOF SEALANT HORIZONTAL, TOP, VERTICAL, LEFT AND RIGHT EDGES OF ARM WHERE IT CONTACTS THE POLE TO PREVENT WATER ENTRY. (SEE FIGURE 2)
3. ATTACH LUMINAIRE/ARM ASSEMBLY TO POLE TOP FITTER BY ALIGNING THREADED HOLE ON POLE TOP FITTER TO BOTTOM HOLE ON ARM.
4. THREAD THE BOTTOM 3/8" BOLT, LOCK WASHER, AND SPLIT WASHER INTO THE LOWER TAPPED HOLE OF THE POLE TOP FITTER FROM INSIDE OF ARM ASSEMBLY AND TIGHTEN.
5. PASS THE TOP 3/8" BOLT, LOCK WASHER, AND SPLIT WASHER THROUGH THE ARM AND INTO THE POLE TOP FITTER. SECURE WITH 3/8" LOCK WASHER AND HEX NUT. TORQUE ALL NUTS TO APPROXIMATELY 20 FT.-LBS.
6. INSTALL THE POLE TOP FITTER/LUMINAIRE ONTO THE TENON. TOP OF THE TENON MUST SEAT AGAINST THE FITTER STOP. LEVEL AND SECURE WITH (8) 3/8" SOCKET SET SCREWS.
7. ROUTE SUPPLY AND GROUND WIRES OVER THE STRAIN RELIEF ROD. TIE OFF WITH TAPE OR WIRE TIE AS SHOWN.
8. CONNECT FIELD SUPPLY AND GROUND WIRES TO LUMINAIRE LEADS. MAKE WIRE CONNECTIONS PER NEC OR APPLICABLE LOCAL CODES.
10. INSTALL POLE TOP FITTER CAP AND SECURE IN PLACE WITH (2) #10-32 PHILLPS PAN HEAD SCREWS.
11. INSTALL PHOTO CONTROL IF USED.
12. CLOSE ARM ASSEMBLY AND SECURE WITH THE (2) 8-32 SCREWS PAN HEAD SCREWS.
13. ENERGIZE LUMINAIRE TO TEST INSTALLATION.



**FIGURE 2**

REMOVE  
HOLE PLUGS  
IF MORE THAN  
ONE LUMINAIRE IS  
NEEDED.



**MOUNTING HOLE PATTERN**

**PHILIPS**

1611 CLOVIS BARKER RD., SAN MARCOS, TX 78666