

# INSTALLATION INSTRUCTIONS

SLENDERFORM POST TOP MOUNTED ON 2 3/8" X 4" TENON

**PHILIPS**

443561200950 REV  
SHEET 1 OF 1


© 2013 Koninklijke Philips N.V. (Royal Philips) All rights reserved.

**IMPORTANT** : READ ALL INSTRUCTIONS BEFORE PERFORMING ANY WORK. BE SURE ALL POWER IS OFF PRIOR TO INSTALLING LUMINAIRES.

**WARNING**: FIXTURE MUST BE GROUNDED IN ACCORDANCE WITH APPROPRIATE CODES. FAILURE TO DO SO MAY RESULT IN SERIOUS INJURY.

NOTE: THIS INSTALLATION INSTRUCTION SHEET IS FOR THE AUTOMATIC PROFILE DIMMING POLE MOUNTING INSTRUCTIONS ARE PROVIDED WITH MOUNTING HARDWARE

1. FIT TENON ADAPTER ONTO TENON AND SECURE WITH PROVIDED 1/4-20 SET SCREWS.
2. CONNECT LEAD WIRES FROM SLENDERFORM TO INCOMING POWER LEADS BY JOINING LIKE COLORS.
3. FIT UNIT ONTO TENON ADAPTER AND SECURE WITH PROVIDED 1/4-20 SET SCREWS.



**PHILIPS**

1611 CLOVIS BARKER RD, SAN MARCOS, TX 78666