

READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING LUMINAIRE
 This luminaire is intended for installation in accordance with the National Electrical Code and local regulations.
 To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electric shock, turn off electricity at fuse box before proceeding.
 Retain these instructions for maintenance reference.

INSTALLATION PROCEDURE OF LYTECASTER 1029 SERIES REFLECTOR TRIMS IN THE 1000P FRAME-IN KIT

CAUTION: READ MARKINGS IN TRIM TO DETERMINE LAMP WATTAGE AND TYPE, ALWAYS USE CORRECT LAMP.

1. FRAME-IN

See Frame-In Kit Instruction Sheet for installation procedure.

2. ROTATE ROTO-CLIPS (Fig. A)

Rotate (3) ROTO-CLIPS so that the short legs extend inwardly toward the center opening.

3. TRIM INSTALLATION

- A. Insert SOCKET CUP into SLOTS in neck of REFLECTOR. (Fig. B)
- B. Push REFLECTOR TRIM straight up into ceiling opening until it is tight against ceiling.
- C. Lamp fixture with recommended lamp wattage end type. (See wattage label.)
- D. Vertical adjustment can be done by inserting a screwdriver into slot in YOKE, and using it as a lever, tilting the YOKE to the desired angle. (Fig. C)
- E. Horizontal adjustment can be done by rotating LAMP/YOKE to desired position.

NOTE: To remove Reflector Trim, turn Reflector Trim counterclockwise while pulling downward.

100P1 also accepts the following Trims: 1005, 1008, 1010, 1011, 1012, 1013, 1013BK 1013WH, 1021, 1022, 1023, 1024, 1035, 1045, 1046, 1071, 1076, 1076WH, 1078, 1082, 1085. Rotate ROTO CLIPS so that the LONG LEGS extend inwardly toward the center opening.

CAUTION: USE ONLY FRAME-IN KITS PROVIDED BY LIGHTOLIER. USE OF OTHER MANUFACTURERS' RFRAME-IN KITS VOIDS THE UNDERWRITERS LABRATORIES LISTING AND COULD CONSTITUTE A FIRE HAZARD.

