



**SlimLux** 

**Configuration Guide** 




# SlimLux is a luminaire comprised of two primary products:

Lightbar – installed below the ceiling, this is the product that is visible from below, and produces light. Driver Pod – installed above the ceiling, this is the product that mains voltage is connected to, and provides low voltage to the lightbar.


#### **Module Dimensions:**

SlimLux is available in nominal 2' (24-1/4, 616mm) and 4' (47-3/16", 1198mm) lengths, and must be directly mounted to main runner NEMA G 15/16" wide t-bar.




### **Driver Pod Dimensions:**

SlimLux driver pod dimensions are the same regardless of the configuration selected. Driver pods are mounted directly to t-bar above the ceiling.




# SlimLux Configuration Guide

# **Application Examples**



### Legend



#### Scenario A

1x 4' Lightbar with 1x SLO4S EM Driver pod

#### Scenario B

3x 4' Lightbars with 3x SL04S Driver Pods

## Scenario C

4x 4' Lightbars with 1x SL04Q Driver Pod

#### Scenario D

8x 4' Lightbars with 1x SL04M Driver Pod

#### Scenario E

4x 2' Lightbars with 1x SL02Q Driver Pod

#### Scenario F

1x 2' Lightbars with 1x SL02S Driver Pod

#### Notes


- Each individual lightbar must be wired back to a driver pod.
- All ports on the driver pod must be connected to individual lightbars.
- Do not power the driver pods until all ports are connected to individual lightbars.
- Lightbars may be installed a maximum of 28ft (8.5m) from the driver pod.
- Driver pods must be ordered according to the lightbar length they are installed with (e.g. 4' driver pod with 4' lightbars)


# SlimLux Configuration Guide

# Installation Guidelines

#### **Continuous Row Guidelines:**

All lightbars must be installed on the main t-bar runners. Up to 30 4' lightbars, or up to 15 2' lightbars may be continuous row mounted without gaps. Additional lightbars in the row require a 2-3/4" gap between to account for a t-bar cross section.





#### Notes

 Labels shown left will be factory affixed next to each bank of secondary ports on the quad (Q) and octo (M) driver pods, and on the end for the single (S) driver pod.

The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract.



2019 Signify Holding. All rights reserved. This document contains information relating to the product portfolio of Signify which information may be subject to change. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereor is disclaimed. All trademarks are owned by Signify Holding or their respective owners.

Signify North America Corporatior 200 Franklin Square Drive, Somerset, NJ 08873 Telephone 855-486-2216 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone 800-668-9008