




PACIFIC LED WT470/480 C/X EL








Installation instructions

Instructions de montage Istruzioni di montaggio
Installation instructions Instrucciones de montaje
Montageanweisung Montážní návod
Montagevoorschrift Montážny návod


Szerelési útmutató
Instrukcja montażu








PACIFIC LED



Date of installation
Data instalacji



4



Type of luminaires	Luminous Flux Lamp in EL mode	Working time in EL mode	Accu Ni-Mh	
	(lm)	(h)	(V)	(mAh)
ELP1	>600	1	7,2	2500
ELP3	>360	3		
ELD1	>600	1		
ELD3	>360	3		

Log book

Księga kontroli

Luminaire no

Oprawa nr:

Location

Lokalizacja:

Installer

Instalator:

Mountage

Montaż:

Date

Data:

Time of emergency mode:

Czas świecenia awaryjnego oprawy: [h]

Test of emergency lighting:

Test zaświecenia awaryjnego:

half - year

półrocze

1 year/rok

Data/Date

Podpis/Signature

2 year/rok

Data/Date

Podpis/Signature

3 year/rok

Data/Date

Podpis/Signature

4 year/rok

Data/Date

Podpis/Signature

I

II

TEST OF EMERGENCY MODE (every 6 month)

TEST ZAŚWIECENIA AWARYJNEGO (co 6 miesięcy)