philips hue

Warnings

Always make sure the luminaire is detached from the mains socket Always make sure the DC cable is detached from the power supply Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	
а	Remove Front ring [7] from Diffuser [4]	
		screwdriver
		screwdriver
d	Unscrew 3pcs Screws [13] and remove Junction box cover [10] from Junction box [11]	screwdriver
е	Unscrew 2pcs Screws and remove Hue Connect [2] from Junction box [11]	screwdriver
f	Remove Driver [1] from Junction box [11]	
g	Remove LED strip [9] from Mounting ring [3]	

*

#	COMPONENT	QTY
1	Driver	1
2	Hue Connect	1
3	Mounting ring	1
4	Diffuser	1
5	5 Upper diffuser	
6	Water proof ring	
7	7 Front ring	
8	8 Outer ring	
9	LED strip	
10	Junction box cover	
11	11 Junction box	
12	12 NUT	
13	13 Screw	
14	14 Water proof plug	
15	Terminal block	
16	16 Screw	

FOR LIGHT SOURCE-LED STRIP REMOVAL PLEASE SEE DOCUMENT 442295215544_L2 Removal and Test Instuction Flex LED Strip

(8)	
\bigcirc	
5-	
1	
(3) (9)	
6	

	STATUS DESCRIPTIO		N
		929003056701	
		Adore Hu	e ceiling lamp chrome 1x27V
NAME Li Ba			LOCAL PART ID
	CHECKED		DATE 2021-09-02



A3-L