
## **PHILIPS** hue



| #  | COMPONENT                  | QTY |
|----|----------------------------|-----|
| 1  | DIFFUSER                   | 1   |
| 2  | SCREW                      | 3   |
| 3  | LIGHT SOURCE - LED MODULE  | 1   |
| 4  | SCREW                      | 2   |
| 5  | HEAT SINK                  | 1   |
| 6  | SCREW                      | 1   |
| 7  | BRACKET                    | 1   |
| 8  | BOX                        | 1   |
| 9  | TUBE                       | 1   |
| 10 | SCREW                      | 4   |
| 11 | FLAT CABLE                 | 1   |
| 12 | SCREW                      | 1   |
| 13 | LIGHT SOURCE - HUE CONNECT | 1   |
| 14 | CABLE                      | 1   |
| 15 | BASE                       | 1   |
| 16 | SCREW                      | 3   |

| SKU          | Color | Country |
|--------------|-------|---------|
| 915005731801 | BLACK | EU      |
| 915005630201 | BLACK | NAM     |
| 915005630301 | BLACK | EU      |

Warnings
Always make sure the luminaire is detached from the mains socket
Always make sure the DC cable is detached from the power supply
Staring at the operating light source may cause eye injury

| # | Disassemble/dismantle steps  | Tools needed                            |  |  |
|---|--|---|--|--|
| а | REMOVE BASE (15) BY UNSCREWING THE SCREWS (16)   | CROSS HEAD SCREW DRIVER                 |  |  |
| b | REMOVE THE TUBE (9) BY UNSCREWING THE SCREWS (10)  | CROSS HEAD SCREW DRIVER                 |  |  |
| С | REMOVE THE DIFFUSER (1)  | FLAT HEAD SCREW DRIVER                  |  |  |
| d | REMOVE FLAT CABLE (11) FROM THE LIGHT SOURCE - LED MODULE (3)                                | -                                       |  |  |
| е | REMOVE LIGHT SOURCE - LED MODULE (3) BY UNSCREWING THE SCREWS (2)                            | CROSS HEAD SCREW DRIVER                 |  |  |
| f | REMOVE HEAT SINK (5) BY UNSCREWING THE SCREWS (4)  | CROSS HEAD SCREW DRIVER                 |  |  |
| g | UNSCREW THE SCREW (6)  | CROSS HEAD SCREW DRIVER                 |  |  |
| h | REMOVE WIRES OF THE CABLE (14) FROM LIGHT SOURCE - HUE CONNECT (13)                          | FLATHEAD SCREWDRIVER OR WAGO TOOL #2065 |  |  |
| i | REMOVE THE LIGHT SOURCE - HUE CONNECT (13) FROM THE BRACKET (7) BY UNSCREWING THE SCREW (12) | CROSS HEAD SCREW DRIVER                 |  |  |

| ST                   | ATUS                                   | DESCRIPTION |                               | DESIGN ID |   |  |      |
|----------------------|--|-------------|-------------------------------|-----------|---|--|------|
|                      |  |             | e Hue ext. pedestal black 1x8 |           |   |  |      |
|                      | Calla Hue ext. pedestal LED black 1x8W |             |                               | DOC 12NC  |   |  |      |
| 2021-04-12 Calla Hue |  | Calla Hue   | ext. pedestal Black 1x8W 24V  |           |   |  |      |
| NAME                 | JZ                                     |             | LOCAL PART ID                 | SH. 1     | SH.   |  | A3-P |
| CHECKED              |  |             | DATE                          |           | CONFIDENTIAL, PROPERTY OF: © 2020 Signify Holding |  |      |