

PHILIPS

hue

Lily
Spot light
Extension




User manual
Benutzerhandbuch
Notice d'emploi
Manual de usuario
Manual do usuário
Manuale d'uso




Incl.

A

B








Excl.










B
→

IP65












4b











5b



6b










- EN** Use only with Hue Low-volt 24V === SELV IP67 LED power supply unit!
- DE** Verwendung nur mit Hue Low-volt 24V === SELV IP67 LED-Stromversorgung!
- FR** Utiliser uniquement avec l'alimentation LED Hue Low-volt 24V === SELV IP67!
- ES** Se utiliza solo con la fuente de alimentación LED Hue Low-volt SELV 24 V === IP67!
- PT** Utilize apenas com fonte de alimentação LED SELV Hue Low-volt de 24 V === IP67!
- IT** Da utilizzare solo con un alimentatore LED Hue Low-volt 24 V === IP67!



Hue Low-volt system (24V)



Choose your power supply unit (PSU)

40W PSU: Connect up to 40W of lights and 35 m of cable.

100W PSU: Connect up to 100W of lights and 30 m of cable.



hue

Signify

I.B.R.S. / C.C.R.I. Numéro 10461
5600 VB Eindhoven,
the Netherlands
00800-74454775

© 2025 Signify Holding
All rights reserved

Last update: 08/2025

www.philips-hue.com

442296669771

