



**Warnings**  
 Always make sure the luminaire is detached from the mains socket  
 Always make sure the DC cable is detached from the power supply  
 Staring at the operating light source may cause eye injury

#	Disassembly instruction	Tools needed
a	Unscrew the 2 screws [1]. Pull the tube [2] out of the base [7] and unplug the flat wire from the light source [5]	Screwdriver T6
b	Pull the diffuser [3] out of the tube [2] and remove the light source* [5]	-
c	Unscrew the 3 screws [6] and remove the foot [11] from the base [7]	Screwdriver T20
d	Unscrew the 2 screws [8] of the cable clamp [9] and 1 screw of the Hue Connect [10]	Screwdriver T10

#	COMPONENT	QTY	SKU	Color	Country
1	M2X8 screw	2	915005986901	White	EU/UK
2	Tube	1	915005987001	Black	EU/UK
3	Diffuser	1	915005987301	White	NAM
4	End Cap	1	915005987401	Black	NAM
5	Light Source	1	929003479601	Oak	EU/UK
6	M4X10 Screw	3	929003479801	Oak	NAM
7	Base	1			
8	M3X6 Screw	3			
9	Cable Clamp	1			
10	Hue Connect	1			
11	Foot	1			

\*  
 FOR LIGHT SOURCE-LED STRIP REMOVAL PLEASE SEE DOCUMENT  
 "200604 - Instruction LED Strip Removal Procedure"

STATUS	DESCRIPTION	DESIGN ID	01	2020-04-15
Gradient Table		DOC L2NC	442295217492	
NAME	Ma Vt	LOCAL PART ID	SH. 1	SH. 511
CHECKED	DATE	2020-04-15	PROPERTY OF: © 2020 Signify Holding	