



#	COMPONENT	QTY
1	COVER	1
2	DIFFUSER	1
3	SCREW	4
4	LIGHT SOURCE - LED MODULE	1
5	SCREW	2
6	CONTROL GEAR - PSU	1
7	SCREW	2
8	CLAMPER	1
9	PLATE	1
10	SCREW	4
11	TERMINAL BLOCK	1
12	BASE	1
13	SCREW	2

Warnings

Always make sure the luminaire is detached from the mains socket
 Always make sure the DC cable is detached from the power supply
 Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed
a	REMOVE BASE (12) BY UNSCREWING THE SCREWS (13)	CROSS HEAD SCREW DRIVER
b	UNSCREW WIRES OF THE CONTROL GEAR - PSU (6) FROM THE TERMINAL BLOCK (11)	FLAT HEAD SCREW DRIVER
c	REMOVE COVER (1) AND DIFFUSER (2) BY UNSCREWING THE SCREWS (10)	CROSS HEAD SCREW DRIVER
d	REMOVE LIGHT SOURCE - LED MODULE (4) BY UNSCREWING THE SCREWS (3)	CROSS HEAD SCREW DRIVER
e	REMOVE WIRES OF THE CONTROL GEAR - PSU (6) FROM THE LIGHT SOURCE - LED MODULE (4)	SOLDER IRON
f	REMOVE THE CLAMPER (8) BY UNSCREWING THE SCREWS (7)	CROSS HEAD SCREW DRIVER
g	REMOVE THE CONTROL GEAR - PSU (6) BY UNSCREWING THE SCREWS (5)	CROSS HEAD SCREW DRIVER

SKU	Color	Country
915005554701	BLACK	EU

STATUS	DESCRIPTION	DESIGN ID
2021-04-12	Drosera wall lantern black 1x12W 176V	DOC 12NC
NAME JZ	LOCAL PART ID	SH. 1
CHECKED	DATE	SH. A3-P