



#	COMPONENT	QTY
1	COVER	1
2	DIFFUSER	1
3	SCREW	4
4	LIGHT SOURCE - LED MODULE	1
5	SCREW	2
6	CONTROL GEAR - PSU	1
7	SCREW	2
8	CLAMPER	1
9	PLATE	1
10	SCREW	4
11	TERMINAL BLOCK	1
12	BASE	1
13	SCREW	2
14	CONTROL GEAR - SENSOR	1
15	SCREW	2
16	CLOSED END CONNECTOR	2

**Warnings**

Always make sure the luminaire is detached from the mains socket  
 Always make sure the DC cable is detached from the power supply  
 Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed
a	REMOVE BASE (12) BY UNSCREWING THE SCREWS (13)	CROSS HEAD SCREW DRIVER
b	UNSCREW WIRES FROM THE TERMINAL BLOCK (11)	FLAT HEAD SCREW DRIVER
c	REMOVE THE CLOSED END CONNECTORS (16)	PINCER
d	REMOVE CONTROL GEAR - SENSOR (14) BY UNSCREWING THE SCREWS (15)	CROSS HEAD SCREW DRIVER
e	REMOVE COVER (1) AND DIFFUSER (2) BY UNSCREWING THE SCREWS (10)	CROSS HEAD SCREW DRIVER
f	REMOVE LIGHT SOURCE - LED MODULE (4) BY UNSCREWING THE SCREWS (3)	CROSS HEAD SCREW DRIVER
g	REMOVE WIRES OF THE CONTROL GEAR - PSU (6) FROM THE LIGHT SOURCE - LED MODULE (4)	SOLDER IRON
h	REMOVE THE CLAMPER (8) BY UNSCREWING THE SCREWS (7)	CROSS HEAD SCREW DRIVER
i	REMOVE THE CONTROL GEAR - PSU (6) BY UNSCREWING THE SCREWS (5)	CROSS HEAD SCREW DRIVER

SKU	Color	Country
915005554901	DARK GREY	EU

STATUS	DESCRIPTION	DESIGN ID
2021-04-12	Petronia IR wall lantern anthracite 1x12	DOC 12NC
NAME JZ	LOCAL PART ID	SH. 1
CHECKED	DATE	SH. A3-P