



-The luminaire shall be installed by a qualified electrician and wired in accordance with the latest IEE electrical regulations or the national requirements. -Do not switch the luminaire on before completing installation.

-The height between luminous surface and ground suggested be more than 5m; and the height between bottom of luminaire and mounting surface must be more than 0.3m.

- If customer require the luminous surface levelness <1, pipe mounting method is recommended, and suggest to use gradienter to precisely measure and adjust.

- If the external flexible cable or cord of this luminaire is damaged. It shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

-The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

-The corrosive atmosphere or hazardous materials such as sulfur, chlorine, phthalate,etc must be avoided during the use and storage.

-Luminaire don't have any evaluation on additional protective measures to prevent luminaire from high-altitude falling and windproof structure, therefore it can't it be used as flood and tunnel luminaire.

- Not suitable for use in harsh vibration and often causing vibration or swinging environment. Also not suitable for area prone to hurricane and extreme winds. - Installer needs to be arrange the Chain / Pipe for mounting. The default product is supplied with a mounting hook.

Do not stare at the operating light source.