

Mercury Vapor lamps

Warnings, Cautions and Operating Instructions

R “**WARNING:** This lamp can cause serious skin burn and eye inflammation from shortwave ultraviolet radiation if outer envelope of the lamp is broken or punctured. Do not use where people will remain for more than a few minutes unless adequate shielding or other safety precautions are used. Lamps that will automatically extinguish when the outer envelope is broken or punctured are commercially available.” This lamp complies with FDA radiation performance standard 21 CFR subchapter J. (USA:21CFR 1040.30 Canada:SOR/DORS/80-381)

WARNING: The following GOOD LAMP PRACTICES are recommended to reduce the possibility of an arc tube rupture and the associated risk of property damage or personal injury.

- (1.) TURN LAMPS OFF AT LEAST ONCE PER WEEK FOR AT LEAST 15 MINUTES, in systems which are otherwise operating on a continuous basis (24 hours/day-7 days/week).
- (2.) RELAMP FIXTURES AT OR BEFORE END OF RATED LIFE. Allowing such lamps to operate until they fail is not advised and may increase the possibility of inner arc tube rupture.
- (3.) OPERATE LAMP WITH PROPER CIRCUITS AND AUXILIARY EQUIPMENT.

CAUTION: Electric discharge lamp-Use only with proper circuits and auxiliary equipment designed to produce established electrical values for this lamp. Operating the lamp improperly may result in damage to equipment or personal injury, for which the lamp manufacturer does not assume any responsibility.

If a lamp bulb support is used, be sure to insulate the support electrically to avoid possible decomposition of the bulb glass. Do not scratch the bulb or subject it to pressure, as it could fail violently. If the outer bulb is broken, turn off the lamp and replace it promptly.

Do not use this lamp in a fixture which redirects a substantial portion of the energy toward the arc tube and its immediate vicinity, as this may lead to very early lamp failure.

NOTICE: For total supply load, add auxiliary (ballast) watts to lamp watts.