



Actinic BL TL-D(K) Secura – additional safety and HACCP approval

Actinic BL TL-D(K) Secura

With an optimized spectrum matching the eye sensitivity of the housefly, Actinic BL TL-D(K) Secura lamps are perfect for attracting insects. They have virtually no UV-B output, and so are perfectly safe. In addition, they have a special "Secura" sleeve that keeps all glass and components together in the case of accidental breakage. This eliminates the risk of glass splinters showering down on food preparation areas, for example. And that is why it meets the strict HACCP requirements. What's more, with the lowest mercury content in the industry and being 100% lead-free, these lamps represent a very good environmental choice.

Benefits

- Perfectly matches the eye sensitivity of houseflies and in this way attracts more insects
- Perfectly matches the eye sensitivity of houseflies and in this way attracts more insects
- · Safe for use
- · Safe for use
- · Good environmental choice
- · Good environmental choice
- · No risk of glass particles
- · No risk of glass particles

Actinic BL TL-D(K) Secura

Features

- Emits long-wave UV-A radiation in the 350-400nm range
- Emits long-wave UV-A radiation in the 350-400nm range
- · UV-B/UV-A ratio less than 0.1 % (UV-B 280-315nm)
- · UV-B/UV-A ratio less than 0.1 % (UV-B 280-315nm)
- 100% lead-free
- · 100% lead-free
- · Low mercury content
- · Low mercury content
- · Shatterproof sleeve
- Shatterproof sleeve

Application

- · Insect traps, Electronic Fly Killers (EFKs)
- · Insect traps, Electronic Fly Killers (EFKs)

Warnings and Safety

- A lamp breaking is extremely unlikely to have any impact on your health. If a lamp breaks, ventilate the room for 30 minutes and remove the parts, preferably with gloves. Put them in a sealed plastic bag and take it to your local waste facilities for recycling. Do not use a vacuum cleaner.
- A lamp breaking is extremely unlikely to have any impact on your health. If a lamp breaks, ventilate the room for 30 minutes and remove the parts, preferably with gloves. Put them in a sealed plastic bag and take it to your local waste facilities for recycling. Do not use a vacuum cleaner.

