






Installation Instructions

Instructions d'installation Instrucciones de instalación 安装指示书

Istruzioni per l'installazione Installatie-instructies إرشادات التركيب Installationsanweisungen インストール手順









© 2018 Signify Holding. All rights reserved. Specifications are subject to change without notice. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. All other trademarks are owned by Signify Holding or their respective owners.

3222 636 40243



22 October 2018



22 October 2018 3222 636 40243 www.philips.com/lighting www.philips.com/lighting

IRT9010 product guide and either the: · ActiLume DALI gen2 OEM application guide

(o)

()+

= IR group A

= IR group C

= IR group D

= IR group E

= IR group F

(default) = IR group B

OccuSwitch DALI user guide

t = 5 s








Installation Instructions

Instructions d'installation Instrucciones de instalación 安装指示书

Istruzioni per l'installazione Installatie-instructies إرشادات التركيب Installationsanweisungen インストール手順









© 2018 Signify Holding. All rights reserved. Specifications are subject to change without notice. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. All other trademarks are owned by Signify Holding or their respective owners.

3222 636 40243



22 October 2018



22 October 2018 3222 636 40243 www.philips.com/lighting www.philips.com/lighting

IRT9010 product guide and either the: · ActiLume DALI gen2 OEM application guide

(o)

()+

= IR group A

= IR group C

= IR group D

= IR group E

= IR group F

(default) = IR group B

OccuSwitch DALI user guide

t = 5 s