

#### **MINI 200**


#### Installation Instruction





### PHILIPS LIGHTING INDIA LIMITED

### **PHILIPS**



#### CAUTION

- 1. Ensure L-N-E is connected in right manner.
- 2. Ensure 3 core CABLE for Connections(Outer diameter 8-12mm, multi strand 1.2 sq. mm thickness) with IP-65 protected cable joint.
- 3. 3 Core cable should be properly connected with ground.
- 4. Ensure luminaire mounting is done properly with specified load(safety issue)
- 5. Product should be operated between 140-270V a.c.
- 6. Use Surge protection (up to 10kV) to protect against surges. Use Type B+C surge type SPD in distribution box to arrest switching and lighting surges
- 7. Luminaire must be brought down from the mounting position for maintenance.
- 8. In case the front glass is found broken/damaged it should not be powered on and is to be replaced before using the luminaire.
- 9. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire shall be replaced.
- FAILURE OF PRODUCT DUE TO NON COMPLIANCE TO ANY OF THE ABOVE, VOIDS WARRANTY OF PRODUCT

## PHILIPS LIGHTING INDIA LIMITED

# **PHILIPS**