



Warnings

Warnings

- Always make sure the luminaire is detached from the mains socket
- Always make sure the DC cable is detached from the power supply
- Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed
a	Remove the bracket (1) from the base (15) by unscrewing screws (2)	CROSSHEAD SCREWDRIVER PZ
b	Remove the terminal blocks (3)	FLATHEAD SCREWDRIVER
c	Remove the CONTROL GEAR – PSU (5) from the base (15) by unscrewing nuts (5).	SOCKET WRENCH
d	Unclamp 2 close end connectors from the low voltage wires from CONTROL GEAR - PSU (4)	PINCER
e	Remove diffuser (6) by unscrewing screws (8)	-
f	Remove flat cable from the LIGHT SOURCE - LED STRIP [14] and LIGHT SOURCE - HUE CONNECT [9]	-
g	Remove low voltage wires of the cable of LIGHT SOURCE - HUE CONNECT (9)	FLATHEAD SCREWDRIVER OR WAGO TOOL #2065
h	Remove the LIGHT SOURCE - HUE CONNECT (9) from the cover (7) by unscrewing screws (10)	TORXHEAD SCREW DRIVER T10
i	Remove HEAT SINK (11) by unscrewing nuts (12).	SOCKET WRENCH
j	Remove light strip (14) acc. to instruction: 442295215544 L2 Removal and Test Instruction Flex LED strip	See instruction.

- A specific Wago tool #2065 can be ordered separately for wire insertion and release tool:



SKU	Color	Country
929003054801	WHITE	EU
929003054901	BLACK	EU

#	COMPONENT	QTY
1	BRACKET	1
2	SCREW	2
3	TERMINAL BLOCK	2
4	CONTROL GEAR - PSU	1
5	NUT	2
6	DIFFUSER	1
7	COVER	1
8	SCREW	3
9	LIGHT SOURCE - HUE CONNECT	1
10	SCREW	2
11	HEAT SINK	1
12	WASHER	3
13	NUT	3
14	LIGHT SOURCE - LED STRIP	1
15	BASE	1

STATUS		DESCRIPTION		DESIGN ID		01	2021-07-23
		Amaze pendant Disassembly instruction					
NAME	He Go	LOCAL PART ID	SH.	2			A3-L
	CHECKED	DATE	2021-07-23				



